

# Removing Screen from the Body of 11.6" Pinebook

## Description


---

This is a guide to remove the screen panel from the body of 11.6" Pinebook.

**STEP 01** Remove the tape that attach on the antenna.




**STEP 02** Unlatch the retaining flap to free the antenna.






**STEP 03** Gently pull out the antenna to disconnect it from the antenna connector.



**STEP 04** Undo the hinges on both sides and the screen connector located on the main board. The hinges are held in place with Philips screws.







**STEP 05** Bend the Pinebook to a 90° angle to separate the screen and the body.

Congratulations! You have now detached the 11.6" Pinebook LCD Screen with the body.

